



155 Pr 244 S

Box 6

Notre-Dame-de-Lourdes, MB

ROG 1M0

SETUP INSTRUCTIONS

Tuff Maternity Pen

Setup instructions

1. Place folded Mat Pen (Maternity Pen) in desired location.
 - Reminder: Head gate location will remain constant.
 - Crowding pen will extend on right side of Head Gate.
2. Remove all ties/wires used for transport.
3. Remove 2 bolts and nuts at top of Mat Pen frame. Keep these for later use in setup process.
4. Swing open long side of frame, open further then required temporarily.
5. Swing open gates on long side of frame, open further then required temporarily.
 - Reminder: Curved panel will be lose when gates are opened and could fall over.
 - Caution is advised.
6. Remove curved panel from mat pen main body and turn over.
7. Place curved panel so that panel feet are at bottom and pin to long side frame.
8. Swing out back gate frame and bolt together with previously removed bolts.
9. Adjust long frame placement until curved panel can pin together with back gate frame.
10. Set up safety gate catch spring.
11. Place gates in desired positions.
12. Ready to use.